



Blue Barrier™ Liquid Wrap 2300

Product Information Sheet

Poly Wall® Building Solutions is an innovator of high-quality, cost-effective, engineered building materials. We stand behind our brand promise — **Moisture and Air Stop Here®**. Visit our website at www.poly-wall.com for the full array of product offerings.

DESCRIPTION

Poly Wall® Blue Barrier™ Liquid Wrap 2300 is a spray applied, fully adhered, permeable, air and moisture building envelope protection membrane. This thin mil, seamless substrate coating can be applied with an approved airless sprayer or power rolled. Liquid Wrap can be sprayed over surfaces and substrates such as OSB, plywood or exterior gypsum that have been prepared per the Poly Wall Blue Barrier Application Guides.

ADVANTAGES

- Great replacement for housewraps
- Exceptional adhesion/Bonds to multiple substrates (OSB, plywood, gypsum, CMU)
- **PERMEABLE**/Allows substrates to breathe
- Low VOC/UV resistant
- Wet surface application/Bonds and cures in wet conditions

WHY USE POLY WALL® BLUE BARRIER™ LIQUID WRAP 2300?

- 60 years of successful waterproofing experience
- When utilized with our Blue Barrier 2200 Joint Filler combines to fill in voids up to 3/4" due to penetrations or dissimilar surfaces.
- Stands up to UV up to 6 months UV Exposure.
- Works as a complete system with our Blue Barrier 2400 Flash 'N Wrap Window and Door Fluid applied Flashing and Waterproofing treatment.
- Can be covered with commonly used cladding/siding systems including heavy veneers.
- Same Technology has been used in Commercial Construction for years.

STORAGE

12 months from manufacture date. Store below 80°F.

LIMITATIONS

- Apply as packaged. Do not dilute or alter.
- Properly dispose of any roller covers and brushes as they will not be reused or cleaned. If you used the plastic trowel or putty knife allow for the product to cure and peel off for the next use.
- When not dispensing the product, cover the bucket with a lid to insure the product is the viscosity you want.
- For optimum results, we recommend this product be applied in 40°F and rising temperatures. However you likely (depending on RH) can apply is down to 25°F. Test a small area to determine how it works on a given day when the temp is less than 40°.
- For extended storage: Prior to re-setting the lid linder, spray a nitrogen blanket to stop the material from prematurely curing. This type of product can be found in "Key Board Cleaner" at office supply stores. Just 2-3 short burst per application is all you need.
- Stains from substrate may transfer due to permeability of product but will not alter performance of product.



**SCAN HERE FOR OUR PRODUCT
INFORMATION SHEET
REGARDING POLY WALL
BLUE BARRIER 2400 & HOW TO
FLASH A WINDOW & DOOR.**



POLY WALL® BUILDING SOLUTIONS:
Moisture and Air Stop Here®
888-976-POLY (7659) • www.poly-wall.com





LIMITED WARRANTY: Poly Wall Building Solutions will replace F.O.B. Ennis, TX, any material with manufacturing defects which cause leaks for a period of 1 year from date of purchase. Poly Wall Building Solutions will not be liable for any other claims or damages, whether direct or indirect, including consequential damages or incidental damages.

Blue Barrier™ Liquid Wrap 2300

TYPICAL PROPERTIES - Cured Properties at 21 days

Hardness, Shore A	40-45
Tensile Strength	90-100 psi
Elongation	225-300%
Tear Strength	50-60 psi
Perm Rating	24 Perms
UV Exposure	6 Months
Solids Content	90% Solids

Uncured Properties

Tack Free Time	<20 minutes
Cure Rate	1/8" - 16hrs.
VOC Content	<0grams/liter

Note: Cure rates will vary based upon the relative humidity of the application environment.

SIZE	PART NUMBER
5 Gallon Pail	PWBB.2300.LW.5

COVERAGE

125* SF/Gallon @ 12 Mil

*Coverage rates will vary depending on substrate porosity.



INSTALLATION GUIDELINES FOR POLY WALL® BLUE BARRIER™ LIQUID WRAP 2300 USED AS AN AIR BARRIER

The installation guidelines provided below are not intended to be full and complete application instructions.

For full air barrier application instructions scan here



STEP 1 - Clean & Prepare the Substrate

- Clean surfaces free of debris, sawdust, contaminants, oils etc.
- In severe cases power wash off debris carefully so not to harm substrates such as OSB.
- Substrate can be damp to touch and Blue Barrier will stick.
- voids in joints, holes and irregular surfaces up to 3/4" can be filled with Poly Wall Blue Barrier 2200 Joint filler applied with a caulking gun and strike smooth with a putty knife/trowel.
- For voids in excess of 3/4" install a closed cell backer rod per manufacturer's instructions or spray urethane expanding foam in the void.

STEP 2 - Penetration Treatment

- Scuff up plastic penetrations such as pipes with sand paper to ensure a good bond with the fluid applied detailing products.
- If you have gaps or voids exceeding 3/4" around the penetrations fill with closed cell backer rod or closed cell urethane expanding foam.
- Caulk the penetration with Poly Wall Blue Barrier 2200 Joint Filler and be sure to carry it on to the penetration itself 2-3 inches. Allow it to set up for approximately 15 minutes.
- Apply Poly Wall Blue Barrier Flash 'N Wrap 2400 over the 2200 and onto the penetration a minimum of 4-inches on and around the entire penetration.
- Allow 30 minutes for detail products to set up and you are ready to apply your air barrier.
- The 2200 and 2400 detail products will be tacky but when ready they should not stick to your finger when touched.

STEP 3 - Applying Air Barrier With Roller

- You have your choice of using either Poly Wall Blue Barrier Flash 'N Wrap 2400 or Poly Wall Blue Barrier Liquid Wrap 2300 when using a hand roller.
- When using a Power Roller we recommend Poly Wall Blue Barrier Liquid Wrap 2300.
- Simply open the 5 gallon bucket of product, no mixing necessary. Save lid liner for later use.
- Start on one end of your building and apply from top of wall downward, then lapping each coat moving horizontally. Your goal is to apply approximately 20 wet mils of product which is enough where you cannot see substrate any longer.
- Completely cover the entire wall substrate around the entire above grade position of the building.
- Carry the coating approximately 4 inches onto the top of the foundation wall which will tie into your foundation waterproofing.
- If you can see substrate through the wet Blue Barrier Liquid Wrap 2300, you are a bit light in coverage. Helpful hint. Try to correct this as you go while the material is still tacky. If additional coats of any Blue Barrier material are required, clean previously applied Blue Barrier with an approved solvent such as Mineral Spirits or Denatured Alcohol to bring the product back to tacky. Apply more Blue Barrier as needed.

STEP 4 - Apply Cladding

- Common cladding/sidings can be installed to Blue Barrier Air Products within 24 hours of installation.

POLY WALL BUILDING SOLUTIONS:
Moisture and Air Stop Here®
 888-976-POLY (7659) • www.poly-wall.com